

## Equipment and Accessories



**A-** Biodify®  
**B-** Cartridge  
**C-** Power Block  
**D-** Wall Mount

### Biodify® Safety Precautions

- Always unplug the unit before moving it.
- The Biodify® Enviro-Biotics™ cartridge should not be refilled with any liquid other than BetterAir's Enviro-Biotics™ Cartridge supplied by the manufacturer. The use of any other liquid will forfeit the warranty.
- Do not immerse in or place the Biodify® near water, sinks or bathtubs.



## Specifications

Dimensions:  
3.9in (h) x 9.8in (L) x 2.1in (w)  
Weight: 1.4 lb  
Power Supply:  
• Input Voltage: 110/230 VAC  
• Output Voltage: 2.4 VDC  
Approvals: CE  
Working Temp: 35-109 F°  
Working Humidity: 85% or less  
Liquid Capacity: 3.8 oz cartridges  
Performance: Up to 800 sqf

**WARNING:**  
**KEEP OUT OF REACH OF CHILDREN AVOID SWALLOWING AND EYE CONTACT.**  
**IF SWALLOWED - drink 1-2 glasses of water**  
**EYES - Flush with water**



## QUICK START GUIDE BIODIFY®



WELCOME TO THE WORLD  
OF BETTER AIR

[www.BetterAirUK.org](http://www.BetterAirUK.org)

Biodify® nourishes your indoor environment with a repetitive flow of Enviro-Biotics™. An environment rich in beneficial bacteria supports your well being and cleans air, surfaces and objects, especially in those hard to reach areas.



Earth Save Products Limited  
Units 6 & 7, Henderson House,  
Hithercroft Road,  
Wallingford, Oxfordshire OX10 9DG  
T: 01865 598158  
E: [info@betterairuk.org](mailto:info@betterairuk.org)  
W: [www.betterairuk.org](http://www.betterairuk.org)

# Getting Started - The Power of Enviro-Biotics™

## Cartridge Installation



1. Remove cartridge chamber cover by an outward/upward motion with minimum pressure.

2. Shake the cartridge well.



3. Remove sealing foil.

4. Insert the cartridge all the way into the chamber in the direction of the arrow printed on the cartridge.



5. Replace chamber cover in a downward/inward motion with minimum pressure, until it locks into place.

## Position of the Biodify®

1. Your Biodify® should be located out of the reach of young children or pets. It is not advised to place the Biodify™ near an open door or a window that leads outdoors in order to obtain maximum coverage indoors.

2. Optimum place for the Biodify® is in the middle of a room. The Biodify® can sit on top of a shelf, a cabinet or a table top. It is also recommended to install the Biodify® in proximity to the electric outlet using the Wall Mount (included)

3. Wall Mount installation for optimal performance:

It is recommended to position the Biodify® wall mount in proximity to an air flow. Drill two screws to fasten the wall mount on the wall. Make sure that there is an electric outlet in proximity to installation for the electric cord to reach

4. Instead of using the Wall Mount, you may place the Biodify® on any flat surface and stabilize it with the provided Pedestals. For best results, place the Biodify® by a bed, close to a carpeted area, table tops, bookcases, shelves etc.



### CAUTION:

Do not place directly under lights or other heat sources over 100 degrees. Damage to the Biodify® may occur.

## Power Connection

1. Connect the power cord to the inlet below the Programming buttons. Plug the power block into an electric outlet within reach of the location you have chosen for your Biodify®.

**WARNING:** The Biodify® should be used only with the power pack provided by the manufacturer.

## Programming

### On/Off Button

1. Press lightly for 2 seconds in order to turn the Biodify® on. Repeat this action when you wish to turn off the unit.



### Operating Buttons (optional)

2. Press "Flake" button in order to release an extra dose of Enviro-Biotics™.

3. Press "Pause" button in order to put the device on sleep mode for 10 hours.

## Cartridge Replacement

1. Cartridge must be replaced when empty, every 2-3 months, depending on settings used.

**IMPORTANT:** Always turn power off when removing and replacing cartridge. Also, power must be turned off before moving the Biodify®.